

INSTALLATION GUIDE

T47A for Shimano – T47A24B



- ! **Read installation guide carefully before installing your Threaded Bottom Bracket.**
- 1 **IMPORTANT:** Apply CEMA anti seize paste on the threads of the frame and the bottom bracket.
- 2 Align the threads of the bottom bracket and the frame and tighten by hand as far as possible. **WARNING: FORCED LOCKING OF UNALIGNED THREADS WILL DAMAGE THREADS!**
- 3 Use a matching tool and a torque wrench and to tighten to a 40-50 Nm torque. Check tightening torque every 6 months.
- 4 Install the protective tube and repeat steps 1-3 to install the bracket on the opposite side of the frame.



COMPATIBLE

Frame shell ID / Width (mm)		Assembling	
T47	77	Road	No spacers required

- For installation of SRAM GXP cranks, add GXP accessory kit PN. SRC-BB-A0012-F.

RECOMMENDED TOOLS

CEMA Bottom Bracket tool 30 mm **SRC-TT-B006D-18**
CEMA Bottom Bracket wrench **SRC-TT-B020**

SPARE PARTS

Spare Part bearing set for CEMA 24 mm BB
SRC-BB-S009C-B Black, Ceramic
SRC-BB-S009S-B Black, Stainless Steel
SRC-BB-S009SG3-B Black, SG3 - Ceramic - COATED

MAINTENANCE

Maintain bearings by cleaning and adding lubricant:

- Every time after riding in poor road conditions or rain.
- Every 3-6 months as a routine maintenance.

Proper maintenance will increase rolling properties, avoid bearing damage and increase lifetime.

Tip! Apply CEMA water repellent paste between bearing and dustcover.